

BRICK & PATIO FLOOR CLEANER

REMOVES LIMESCALE

PROBLEM SOLVING ACID CLEANER

FAST WORKING

CLEANS CEMENT & GROUT LINES

015.620

102

DESCRIPTION

MERLIN 102 BRICK & PATIO FLOOR CLEANER is suitable for cleaning and descaling brick, stone and concrete, quarry tiles etc. MERLIN 102 BRICK & PATIO FLOOR CLEANER can also be used for metal de-rusting.

USES

MERLIN 102 BRICK & PATIO FLOOR CLEANER is suitable for cleaning and descaling brick, stone and concrete, quarry tiles etc.







DILUTIONS AND DIRECTIONS

Initial cleaning and concrete etching, dilute 1 part MERLIN IO2 BRICK & PATIO FLOOR CLEANER to 4 parts water. Brush or spray. Allow to penetrate 5 to 10 minutes and then rinse. For stubborn deposits, dilute 1 part MERLIN IO2 BRICK & PATIO FLOOR CLEANER to 4 parts water. Brush on. Allow to descale, rinse and allow to dry. Paint or protect from corrosion immediately.



N.B. Do not use on or near linoleum floors, terrazzo, marble, acid sensitive stone, stainless steel, chrome or enamel. Regular use on concrete will cause deterioration and is not recommended. Descaled metal should be painted immediately to prevent rusting.



SAFETY INFORMATION

Keep out of reach of children. Causes severe skin burns and eye damage. Harmful if inhaled. Do not breathe spray. Avoid breathing spray. Wash hands thoroughly after handling. Use only outdoors or in a well ventilated area. Wear eye protection, protective gloves, protective clothing. IF INHALED: Remove victim to fresh air and keep at rest in a position comfortable for breathing. IF SWALLOWED: Rinse mouth. Do NOT induce vomiting. IF ON SKIN(or hair): Wash with plenty of soap and water. If skin irritation or rash occurs: Get

medical attention. **IF IN EYES:** Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Get immediate medical attention. Take off contaminated clothing and wash before reuse. Store locked up.

Contains Hydrochloric acid.





