

# HEAVY WATER DISHWASH LIQUID

039.140

**ORDER CODE** 

**C10** 

- POWERFUL REMOVES STUBBORN SOILSTAINT-FREE & NON FOAMING FORMULA
- EFFECTIVE IN BOTH HARD & SOFT WATER

## **DESCRIPTION**

MERLIN C10 HARD WATER DISHWASH LIQUID is a powerful detergent for machine dish-washing that removes stubborn soiling with ease. MERLIN C10 HARD WATER DISHWASH LIQUID is a high quality product which ensures excellent results consistently in both soft and hard water areas.

### **USES**

An anti-corrosive agent has been added to the formula to protect the dishwashing machine. Ideal for washing cutlery, crockery, stainless steel and utensils. Suitable for all dish washing machines in food and catering establishments. Can be used as an effective detergent for tray washing machines.





# **DILUTIONS AND DIRECTIONS**

Put the dosing tube into the container of MERLIN C10 HARD WATER DISHWASH LIQUID, so that it reaches the bottom. The pre-set dosing unit will automatically dispense MERLIN C10 HARD WATER DISHWASH LIQUID into the machine.



Dilute 2 - 4 mls per litre of water.

N.B. Do not use on aluminium, zinc, magnesium and their alloys.

### **SAFETY INFORMATION**

Causes severe skin burns and eye damage. **Keep out of reach of children**. Wear eye protection, protective gloves. Wash hands thoroughly after handling. **IF ON SKIN (or hair)**: Take off immediately all contaminated clothing. Rinse skin with water or shower. **If skin irritation occurs**: Get medical advice/attention. **IF IN EYES**: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. **If eye irritation persists**: Get medical advice/attention.

Take off immediately all contaminated clothing. Wash contaminated clothing before reuse. Store locked up. For professional use only.











