



EMULSION FLOOR POLISH

ORDER CODE

012.009

F08

- MOP ON & LEAVE TO DRY TO A HARD SHINE
- MACHINE BUFFING IMPROVES WEAR RATE & SHINE
- EXCELLENT SLIP RESISTANCE

DESCRIPTION

MERLIN F08 EMULSION FLOOR POLISH is one of the highest quality acrylic polymer polishes on the market. Formulated with thermoplastic polymers. **MERLIN F08 EMULSION FLOOR POLISH** just gets tougher and more slip resistant each time its buffed. **MERLIN F08 EMULSION FLOOR POLISH** is not harmed by cleaning materials, but is stripped using **MERLIN F01 RINSE FREE FLOOR POLISH REMOVER** or **MERLIN F02 HEAVY DUTY FLOOR POLISH REMOVER**.


USES

MERLIN F08 EMULSION FLOOR POLISH is suitable for use on PVC, thermoplastic floors, linoleum, rubber, sealed cork, sealed wood, asphalt, terrazzo, marble and stone.

MERLIN F08 EMULSION FLOOR POLISH is suitable for hospital corridors and wards, schools, offices, shops, stores, airports, etc.




PVC




MARBLE



LINOLEUM



WOOD



RUBBER

DIRECTIONS


PREPARATION: For optimum results thorough preparation of the floor must be undertaken. The floor must be thoroughly cleaned to completely remove dirt, grease and old polish films by using a quality floor polish remover such as **MERLIN F01 RINSE FREE FLOOR POLISH REMOVER** or **MERLIN F02 HEAVY DUTY FLOOR POLISH REMOVER**. The floor must be well rinsed with water to remove any stripper and allowed to dry before applying **MERLIN F08 EMULSION FLOOR POLISH**.



APPLICATION: Apply a generous film of **MERLIN F08 EMULSION FLOOR POLISH** using a clean mop or polish applicator. Drying time is normally around 30 minutes, then a second coat is applied and allowed to dry. Coverage is dependant on the property of the floor covering. In general 5 litres of product will cover approximately 250 square metres of floor. The mop may be cleaned with cold water after use.

SAFETY INFORMATION

Keep out of reach of children. IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing. Contains chloromethylisothiazolone, methylisothiazolone. May produce an allergic reaction. For professional use only.



pH
8

5L



0345 565 0939 | SALES@SELDRAM.CO.UK | WWW.SELDRAM.CO.UK